

FIRE BIRD



FIRE BIRD

- 1 OU 2 JOUEURS
- INTRODUIRE LES PIÈCES
- SÉLECTIONNER 1 OU 2 JOUEURS
- AVEC LE LEVIER «CONTROLE» DÉPLACER LE VAISSEAU HORIZONTALEMENT AFIN D'ÉVITER LES OISEAUX
- LE VAISSEAU EST ÉQUIPÉ DE MISSILES ON PEUT TIRER 4 ROQUETTES À LA SUITE
- QUAND VOUS APPUYEZ SUR LE BOUTON «WARP» LE VAISSEAU MONTE, DEVIENT INVINCIBLE ET PEUT DÉTRUIRE LES OISEAUX PAR SIMPLE CONTACT (1 WARP PAR VAISSEAU)
- 1 BONUS PAR TABLEAU QUAND TOUS LES OISEAUX SONT DÉTRUITS
- 1 VAISSEAU SUPPLÉMENTAIRE À PARTIR DE 5000 POINTS
- QUAND TOUS LES VAISSEAUX SONT DÉTRUITS PAR LES OISEAUX LA PARTIE EST TERMINÉE

- 1 OR 2 PLAYERS
- INTRODUCE COINS
- SELECT 1 OR 2 PLAYERS
- TO AVOID BIRDS REMOVE THE SHIP HORIZONTALLY WITH THE CONTROLE HANDLE
- THE SHIP IS EQUIPPED WITH MISSILES AND 4 ROCKETS CAN BE FIRED SUCCESSIVELY
- WHEN YOU PUSH ON THE WARP BUTTON, THE SHIP IS GETTING UP AND IT CANNOT BE KNOCKED OUT. SO, IT CAN KNOCK OUT BIRDS ONLY BY TOUCHING THEM. (1 WARP FOR A SHIP)
- 1 BONUS PER BOARD WHEN EVERY BIRD IS KNOCKED OUT
- 1 EXTRA SHIP FROM 5000 POINTS
- THE GAME IS OVER WHEN EVERY SHIP IS KNOCKED OUT BY BIRDS

EMPEREUR



100 pts

AIGLE



50 pts

FAUCON



20 pts

BOMBE



50-100-150-200

4

ROQUETTES

DÉTRUITS PAR

2

ROQUETTES

1

ROQUETTE

1

ROQUETTE

EMPEROR



100 pts

EAGLE



50 pts

FALCON



20 pts

BOMB



50-100-150-200

4

ROCKETS

KNOCKED OUT BY

2

ROCKETS

1

ROCKETS

1

ROCKETS

	TABLE TABLE MODEL	MEUBLE UPRIGHT MODEL
HAUTEUR-HEIGHT	ADJUSTABLE 600 à 750 mm	1680 mm
LARGEUR-WIDTH	880 mm	615 mm
PROFONDEUR-DEPTH	550 mm	700 mm
TENSION-POWER	240 V-175 W	240 V-190 W
POIDS-WEIGHT	55 kg	100 kg

REGLAGES - ADJUSTMENT	
NOMBRE DE BASES NUMBER OF SPACE SHIP	3 - 4 - 5 - 6
MONNAYEUR COINAGE	1 PIÈCE / 1 PARTIE 1 COIN / 1 PLAY 2 PIÈCES / 1 PARTIE 2 COINS / 1 PLAY 3 PIÈCES / 1 PARTIE 3 COINS / 1 PLAY 1 PIÈCE / 2 PARTIES 1 COIN / 2 PLAYS
BONUS SCORE POINT FOR EXTRA SHIP	5000 - 8000 POINTS



rené pierre s.a.

B.P. 338
71107 CHALON-SUR-SAONE

Tél. (05) 46.55.45

Telex: Pterpax 800 824 F